

8 ZONE PROGRAMMING STATUS LABEL



	ZONE 1	ZONE 2	ZONE 3	ZONE 4	ZONE 5	ZONE 6	ZONE 7	ZONE 8
ROOM								
SET A								
SET B								
SET C								
SET D								

STATUS KEY:

E = ENTRY / EXIT
A = ACCESS
t = TAMPER
I = IMMEDIATE
o = OMITTED
H = 24HOUR
F = FIRE
Y = MOMENTARY
d = LATCH
KEYSWITCH
KEYSWITCH

ENTRY/EXIT TIME SECS

SERVICE TIMER SET

BELL OUTPUT
SAB SCB

COMMS DELAY SECS

BELL TIME MINS

BELL DELAY MINS

PIR LEADS
 ENABLED
 DISABLED

ENGINEER

INSTALLATION DATE

INSTALLATION CO

SERVICE DUE DATE

STERLING™ 10

USER GUIDE



Technical Support Tel 0930 107800 calls to this number will be charged @ £0.50 per minute

WELCOME

Thank you for buying the Sterling 10. The Sterling panel uses the latest technology in design and manufacture.


As the end user of the Sterling this manual is written to help you use the functions of your alarm system enabling you to get the best out of your system. Once you are familiar with the panel and its functions it is advisable to change the factory set 'Master and User' codes.

NOTE: The fire zone is intended as an extra feature to the alarm system and must not be regarded as a total fire protection system.

There are two levels of user access to the system:

The **Master Code (Code 1)**, access to all user functions and programming features.

The **User Codes (Codes 2 to 7)** - 6 codes, allow setting / unsetting of the panel, enabling and disabling of the door chime and viewing of the event log only.



Change Text

Press the **FUNC** key. Use the **▼** scroll key to display CHANGE TEXT and press the **FUNC** key to accept. USER 1 will now be displayed, use the scroll keys to display the text to change. When the required user is displayed the text can be changed by using the number keys 1 to 9. Each key has been assigned three letters of the alphabet, by pressing the key several times the number and letter sequence will be scrolled through.

To insert spaces between text press the **0** key twice.

When the desired letter or number is displayed use the **◀ P.A.** and **▶ FIRE** scroll keys to move between segments on the display and when the text is complete press the **FUNC** key to accept, the dual tone will be heard on acceptance. The **FUNC** key must be pressed or the text changes will not be accepted. Use the **▼** key to scroll to EXIT and press **FUNC** to accept.

AC Mains Loss

If the AC mains fails and there is no power to the system, (Only battery power) power fail will be shown on the LCD display with a fault tone, every 5 secs. Panel will automatically run off backup battery when there is a mains fail.

To reset press **FUNC**

System Faults

There are 4 fault conditions automatically detected by the Sterling 10. The user is informed of a fault via the LCD display. The LCD will illuminate and an error tone will be emitted every 5 seconds when the panel is in day mode, press the function key to stop the error tone. The LCD display will remain until the fault has been corrected.

To determine the fault go into the log by entering **FUNC 2**. Fault will be displayed.

1. Bell Fuse Failure.
2. Auxiliary Fuse Failure.
3. Telephone Line Failure.
4. Mains (AC) Failure.

Walk Test Mode

Enter **FUNC** and use the **▼** key to scroll to 'WALK TEST' and press the **FUNC** key to accept. Use the **▼** key to select the set required whilst in walk test and press the **FUNC** key to accept.

Enter **X X X X** (master code) after the countdown timer has stopped the system is ready to be tested.

When the walk test mode is enabled the keypad will display any activated zones. This enables all the zone configurations to be walk tested individually. The walk test mode is cleared when the panel is unset. Any activated zones will be entered into the event log. Zones programmed as Keyswitch zones when activated in walk test will not be entered in the event log.

Changing Master and Limited User Codes

Master Code:

Enter **FUNC** and use the **▼** key to scroll to 'CHANGE CODES' and press the **FUNC** key to accept.

Enter the master user code , **X X X X**

Enter **1**

Enter the new code twice as per the display prompts, three tones will be heard on acceptance of each command, a single low tone indicates programming not accepted.

Master code cannot be deleted.

Limited User Code:

Enter **FUNC** and use the **▼** key to scroll to 'CHANGE CODES' and press the **FUNC** key to accept.

Enter the master user code , **X X X X**

Enter **2** to **7**

Enter the new code twice as per the display prompts, three tones will be heard on acceptance of each command, a single low tone indicates programming not accepted.

To delete a user code press the **▲** key after **2** - **7** is entered.

MASTER AND LIMITED USER FUNCTIONS

Setting The Panel

Enter **X X X X** (User Code) **SET** and then **A B C** or **D**

for set required.

Refer to the Zone Programming Status Label to see how each Set was configured by the installation engineer.

Setting the Panel when Mains Fails

Under normal operation the panel will indicate a fault condition if the AC supply is disconnected. It will still be possible to Set and Unset the control panel during a mains fail if allowed by the engineer, and no further action is required. Full functionality of the control panel is available during mains fail.

Silent Setting The Panel

Enter **SET** and then **A B C** or **D** for set required.

A dual tone will be heard on acceptance of the command and another dual tone will be heard when the panel is set.

Push To Set (PTS)

Set the panel in any of the above methods, the panel will count down but will not set until the PTS button is pressed.

Set With Omits

Enter: **FUNC** and use the **▼** key to scroll to 'OMIT ZONE' and press **FUNC** key to accept.

'SET A' is now displayed, use the **▼** key to scroll through set A, B, C and D and press **FUNC** to accept set required. 'ENTER CODE' **X X X X** (user code),

display reads 'OMIT ZONES' use the **▲** and **▼** keys to scroll through the zones and the **SET** key to select the zone or zones to be omitted. After all the required zones have been selected press the **FUNC** key to accept programming.

Exit timer starts countdown.

(Note: it is not possible to omit all zones)

Unsetting The Panel

The panel may be unset by entering the building via the entry/exit route and then entering either the Master Code or any of the User Codes.

Enter (X) (X) (X) (X) (User Code)

Reset After Alarm Condition

The user code should be entered twice to reset the system after an alarm condition

Enter (X) (X) (X) (X) User code to stop alarm

Enter (X) (X) (X) (X) User code to reset the system

If the panel will not reset then your installer has enabled engineer or Anti -code reset, please contact your installation company.

Duress Set/Unset

Enter (X) (X) (X) (X) (User Code) Reverse the last two digits of the code. The panel will then appear normal but a silent PA will be sent to the Alarm Receiving Centre (on a connected system).

Personal Attack Alarm (PA)

To Activate the Personal Attack Alarm Enter (FUNC) (P.A.) Enter a user code to cancel.

Fire Alarm

To Activate the Fire Alarm Enter (FUNC) (FIRE) Enter a user code to cancel.

Turning Chime On and Off (Panel must be in 'day' mode)

Enter (FUNC) and use the (V) key to scroll to 'SELECT CHIME' and press (FUNC) key to

accept. The display now reads 'CHIME ON (A) OFF (V). To turn the chime on

press the (A) key or to turn the chime off press the (V) key. A (A) symbol will be displayed in the top left hand corner of the display to indicate the chime is turned on.

Reading The Event Log

Panel must be in 'day' mode and Unset by the Master User.

Enter (FUNC) (2) The most recent event stored in the log will be displayed.

If the up arrow key (A) is pressed the previous log entry will be displayed.

Similarly if the down arrow key (V) is pressed the next most recent entry will be displayed. The event log may be scrolled backwards and forwards using the up and down arrow keys to allow the last 100 events to be viewed.

To leave this function press the (FUNC) key.

An error tone will be produced if an attempt is made to scroll outside either end of the event memory log.

MASTER USER ONLY FUNCTIONS

Event Log Reset

Enter (FUNC) and use the (V) key to scroll to 'CLEAR LOG' and press (FUNC) key to accept and clear the event log. A two tone sound will be heard on acceptance. This feature will only operate if, whilst programming, the engineer selected the feature allowing the Master User only to clear the event log.

System Test

Enter (FUNC) and use the (V) key to scroll to 'SYSTEM TEST' and press (FUNC) key to accept.

Press any numeric key to complete the following tests.

- | | | |
|------|----|---------------|
| Test | 1) | Display test |
| | 2) | Strobe test |
| | 3) | Bell test |
| | 4) | Sounders test |

To exit test mode press the (FUNC) after the sounder test.